

Targus Bluetooth Thumbpad

Driver Installation Guidelines

Part #: ACB31UK/FR

Please follow these instructions to successfully install the ACB31 driver onto your device:

- 1) Download driver from our website, from the product web page.
- 2) Run driver program, selecting Keyboard layout and Device Operating System as appropriate.
- 3) Please reboot your device
- 4) Open the driver software that should now be installed on your device. On Windows Mobile PPC devices, this is located in Settings>System.
- 5) The driver should show a screen displaying the device code of the unit and request an Unlock Code. On Palm devices, you should open the options menu of the driver then select registration.
- 6) Browse to http://www.driversandsupport.com/targus_unlock/unlock.php
- 7) When requested, please input your name, e-mail, and BD ADDR from the back of the keyboard and the Device code shown by the unit.
- 8) Select "Unlock Now" button and then input the Unlock Code that is generated into the device.
- 9) The main screen of the driver software will now be displayed. Please put the keyboard into pairing mode (please check the user guide for instructions on how to do this) and then select "Active Driver".
- 10) The keyboard should then connect to the device, and be available for use.

If you are having any difficulties with this process please contact us via the link below:

English: <http://www.targus.com/uk/support.asp>

French: <http://www.targus.com/fr/support.asp>

