



Power your laptop anywhere



CHOOSE THE RIGHT POWER ADAPTOR FOR YOUR LAPTOP:

- 1 Identify your laptop model on the next page to determine the Targus power products that you can choose from.
- 2 Determine where you want to use your power supply (At home or in the Car or Plane)
- 3 Ensure that the tip required for your laptop is included in the pack, if the required universal** tip is not included simply call Targus and we will send you your free tip.

NEED FURTHER HELP CHOOSING THE RIGHT POWER ADAPTOR & TIP FOR YOUR LAPTOP?

Our customer service team are now available late night Thursday & Friday as well as Saturday & Sunday to assist.

Simply Freecall Australia: 1800 641 645 or New Zealand: 0800 633 222

Power Adaptors	Universal**		Replacement AC	
Product Name	Universal 90 Watt Wall Power Adaptor	Universal 90 Watt Wall, Auto/Air Power Adaptor	Home/Office 75 Watt AC Laptop Power Adaptor	Home/Office 90 Watt AC Laptop Power Adaptor
Product Code	APA64AU	APM64AU	APA02AU	APA03AU
Voltage Output:	Universal** Output voltage set by tip	Universal** Output voltage set by tip	15 - 16 V	18.5 - 20 V
Ideal for	Home	Home, Car & Plane	Home	Home
Power Input:			 (15v Laptops)	 (19v Laptops)
Peripheral power for Accessories (APP20AP)	Optional	Optional	X	X
Tips Included in Pack:	102, 104, 201, 202, 203, 204, 205, 206, 207, 209	102, 104, 201, 202, 203, 204, 205, 206, 207, 209	M, N, P	N,R, P, S, T, U

* APP2001US - 15 Watt Mobile Peripheral Power Adaptor for accessories is available seperately

** Please check the Targus website (www.targus.com/au) or call Targus on the numbers above for full compatibility on Universal Power Adaptors - alternatively check the listing below.

Revised for products effective January 2009

If your laptop model is not listed on this chart or on the back of the pack, please contact Targus on the numbers below. If your tip is available and not included in the pack, Targus will supply your first tip for FREE.

WARNING: Care must be taken to ensure the correct tip is selected for your computer (laptop or device) as Targus Australia Pty Limited will not accept responsibility for any consequential damage upon the use of the incorrect power tip. It is stressed damage can be caused by the use of incorrect power tips. Compatibility is determined by Targus and in no way suggests endorsement by laptop manufacturers. Warranty details for Targus power adaptors are outlined on the product packaging.

Targus is a trademark of Targus and all other marks shown are the property of their respective owners

Australia: 1800 641 645

New Zealand: 0800 633 222

www.targus.com/au



Power your laptop anywhere



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP464AU 90W AC/DC - AP464AU	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Acer	AcerNote	390, 367D, 367T	206	✗	P
	AcerNote	350, 355, 356, 374, 370C, 850C	206	✗	✗
	AcerNote Light	350, 360, 370, 372, 373, 380, P100, 370C, 370P, 370PC, 373+	206	✗	✗
	Anywhere	1100LX, 1120LX	206	✗	P
	Aspire	5024, 5101WLMi, 5102AWLMi, 5102WLMi, 5104WLMi, 5105WLMi, 3022WLMi, 5002WLMi, 5003WLMi, 5100, 5100-3357, 5100-3577, 5100-3583, 5100-3825, 5100-3949, 5100-3959, 5100-5328, 5100-5840, 5100-5873, 5570-2067, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421	207	✗	✗
	Aspire	3613, 3623, 3624, 1642, 3002LC, 3002LMI, 3002WLC, 3050-1594, 3614WLMi, 3618AWLCi, 3620, 3622WXCI, 3623NWXMI, 3623WLCi, 3623WXCI, 3623WXMI, 3624WXCI, 3624WXMI, 3634WLMi, 3680-2022, 3690-2710, 3993WLMi, 5512FWLM, 5512WLMi, 5514WLMi, 5514WXMI, 3022WLMi, 3508, 5670WLMi	207	✗	T
	Aspire	3053WXMI, 4220-200508, 4520-5A0508, 5520G-301G12, 5520G-402G16, 9300WLMi, 9305WSMI, AS3054WXMI, AS5102AWLMi, AS5103WLMi, AS5104WLMi, AS5105WLMi, S9305WLMi, 3104LMI, 4520-301G12, 5100-3372, 5315, 5520G-502G16, 5570z, 5580-6432, 7520G-0602G20, AS5103WLMi, AS9305WLMi	102	✗	✗
	Aspire	3683WXMI, 5600, 5044WLMi, 5601AWLMi, 9425WSMI, 9500	102	✗	T
	Aspire	3023, 3025, 4920G, 5610 Series, 5610-2273, 5610-4537, 5610-4610, 5610-4648, 5612WLMi, 5710 Series, AS4315, AS4920, AS5520, AS5702, AS5720, AS5920	102	✗	✗
	Aspire	5670	206	✗	P
	Aspire One	AOA110, AOA150	102	✗	T
	Extensa	5220	207	✗	✗
	Extensa	2300, 3000	207	✗	T
	Extensa	900, 366D, 368D, Ess3-391T	206	✗	✗
	Extensa	515	104	P	✗
	Extensa	355, 500, 600, 501DX, 501T, 502D, 503DX, 505DX, 506DX, 610CD, 610CDT	206	✗	✗
	Extensa	2900	102	✗	✗
	Ferrari	3000LMI, 3400LMI, 4005LMI, 4006LMI, 4006WLMi	206	✗	P
	Tablet	TMC104TCi, TMC110TCi, TMC110Ti	207	✗	T
	TravelMate	C110CTi, C110Ti, C300, TMC110	207	✗	✗
TravelMate	380, 2300, 2400, 2410, 2450, 2480, 3210, 3220, 3230, 4000, 4060, 4070, 4080, 4100, 6000, 8000, 8104, 8105, 230, 230x, 230xc, 230xv, 230xv-PRO, 2310 Series, 2350 Series, 2480-2153, 2480-2551, 2480-2705, 2480-2779, 290, 291, 3000 Series, 3002WTMI, 3004WTMI, 3010 Series, 3200 Series, 4050 Series, 4061, 4062, 4064, 4150 Series, 4600 Series, 8100 Series, 8100A, 8104WLMi, C110, TM220, TM230, TM260, TM270, TM279, TM280, TM350, TM360, TM370, TM380, TM520, TM530, TM610, TM620, TM630, TM660, TM730, TM740, TM800, TMC113LCi	207	✗	T	
TravelMate	512DX, 512T	104	P	✗	
TravelMate	505DX, 506T, 507DX, 507T, 524TX, 524TXV	206	✗	T	
TravelMate	4072, 4074	207	✗	✗	
TravelMate	3280, 3290, 4220, 4270, 5610, 5620, 6410, 6460, 8210, 2600, 4200 Series, 4200-4091, 4200-4320, 4200-4493, 4200-4854, 5710 Series, 6410-6189, 6410-6248, 6460-6263, 6460-6752, 6492, 6592, 7720, 8200 Series	102	✗	✗	
TravelMate	2413	102	✗	T	



Power your laptop anywhere



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP66AU 90W AC/DC - AP16AU	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Asus	Asus	A2L, A3F, A3N/L, A6F, A6G, A6K, A6L, A6Ne, A6U, A6Va, B1, L2B, L2E, L3C, L4E, L4H, L4R, M2C, M2E, M2N, M2Ne, M3N, M3Np, M5A, M5Ae, M6A, M6C, M6Ce, M6N, M6Ne, M6Rf, M7V, M7VP, S1N, S5A, W3A, W3N, W3V, W6A, Z61Ae, Z71A, Z71V, Z71Vp, Z91N/L, Z93E, L3D, W5 Series, W5A, W5Ae, W7J	206	✗	✗
	Asus	A3E, A3G, A3N, A5E, A5Ec, A7 Series, A8 Series, F7000, L1 Series, L1B, L2 Series, L3, L4, L7 Series, L8 Series, M5000, M5200, M5200N, M5N, M6000, M6000C, M6000N, M6000R, M6R, M6V, M7A, S1A, S300N, S5, S5200N, S5N, S6F, S8 Series, T9 Series, V1J, V1JP, V6Z61A, W1000, W1-745, W1GC, W1N, W1NA, A2C, A2Lp, A6000, A6J, A6JA, A6Jc, A6Je, A6Jm, A6KM, D1, F3F, F3J, F3JV, L3H, L3S, L3Tp, L4L, M6Va, PRO30, PRO31J, PRO31P, W1V, W2V, W7	206	✗	P
	Grandio	F7400, L7000, L7000C, L7200, L7300	102	✗	T
BenQ	Joybook	2100, 2100e, 3000, 3000v1, DH5000, DH5100, S100, V11, V12, V33, V37	207	✗	T
	Joybook	527, 5000, 5100, 5120, 6000, 7000, 5100N, 5100U, A82, R53, S52, S52E, S53, S53W	102	✗	✗
	Joybook	DH7000, S72 Series	102	✗	T
	Joybook	2100, 8000, 8100, A32, A32E, A2400H	206	✗	P
Compaq	Amanda	110, E500, E500S, E700, M300, M700, V300	102	✗	✗
	Evo	N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800v, N800w	102	✗	✗
	Evo	N115, N160, N180	206	✗	P
	Evo	N1000v, N1015v, N1020v	201	✗	✗
	Evo	N1020c	201	✗	T
	Presario	2200, 2200LA, 2201US, 2202AL, 2203AL, 2203AP, 2203US, 2204AL, 2204AP, 2204US, 2205AL, 2205AP, 2206AL, 2206AP, 2207AP, 2208AP, 2209AP, 2209CL, 2210AP, 2210CA, 2210US, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2220AP, 2221AP, 2222AP, 2223AP, 2223US, 2224AP, 2225AP, 2226AP, 2226CL, 2227AP, 2227US, 2228AP, 2229AP, 2230AP, 2231AP, 2231US, 2232AP, 2232US, 2233AP, 2234AP, 2235AP, 2236AP, 2237AP, 2238AP, 2239AP, 2240AP, 2241AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2248AP, 2249AP, 2250AP, 2251AP, 2252AP, 2253AP, 2254AP, 2255AP, 2256AP, 2258AP, 2259AP, 2260AP, 2261AP, 2800US, 2801EA, 2802EA, 2803EA, 2804EA, 2805US, 2806AP, 2807EA, 2809FR, 2810CA, 2811CL, 2812EA, 2813AU, 2814AP, 2815LA, 2816EA, 2817AR, 2818AP, 2819AP, 2820AP, 2821SC, 2822AP, 2823AP, 2825AP, 2826TC, 2827AP, 2828AP, 2830EA, 2832AP, 2835AP, 2838AP, 2840TC, 2845AP, 2853AP, 2857AP, 2858AP, 2860AP, 2861AP, 2862AP, 2863AP, 2864AP, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2887AP, 2888AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 305, C300EA, C300EU, C302NR, C303NR, C304NR, C306US, C307NR, C310EA, C310EU, C350EA, C350EU, C500EA, C500EU, C501NR, C501TU, C502CA, C502EA, C502EU, C502TU, C502US, C503TU, C503WM, C504EA, C504EU, C504TU, C504US, C506CA, C506TU, C507US, C508US, C509NR, C518LA, C540EA, C542EA, C551NR, C551TU, C552CA, C552TU, C552US, C553TU, C554US, C555EA, C555EU, C555TU, C556CA, C556TU, C557CL, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C570EA, DV6000T, F502EA, F502EU, F545EA, F545EU, M2000, M2000Z, M2001AL, M2001AP, M2001EA, M2001xx, M2002AL, M2002AP, M2003AL, M2003AP, M2004AP, M2005AP, M2005US, M2006AP, M2007AP, M2008AP, M2009AP, M2010AP, M2010CA, M2010EA, M2010US, M2011AP, M2011EA, M2012AP, M2013AP, M2014AP, M2015AP, M2015LA, M2016AP, M2017AP, M2018AP, M2019AP, M2019EA, M2020AP, M2020EA, M2021AP, M2022AP, M2023AP, M2024AP, M2025AP, M2026AP, M2027AP, M2028AP, M2029AP, M2030AP, M2030EA, M2031AP, M2031EA, M2032AP, M2033AP, M2034AP, M2034EA, M2035AP, M2035EA, M2036AP, M2037AP, M2038AP, M2039AP, M2040AP, M2041AP, M2042AP, M2043AP, M2044AP, M2045AP, M2046AP, M2046EA, M2047AP, M2048AP, M2049AP, M2050EA, M2051AP, M2052AP, M2052EA, M2053AP, M2054AP, M2054EA, M2055AP, M2055EA, M2065EA, M2070EA, M2070US, M2071EA, M2075EA, M2099xx, M2101EA, M2101US, M2105CA, M2105EA, M2105US, M2108EA, M2108US, M2113EA, M2125EA, M2130EA, M2131EA, M2150EA, M2175EA, M2200, M2201AP, M2201EA, M2201TU, M2202AP, M2202TU, M2203AP, M2204AP, M2205AP, M2205EA, M2206AP, M2207AP, M2207EA, M2208AP, M2209AP, M2210AP, M2211AP, M2212AP, M2213AP, M2214AP, M2215AP, M2215EA, M2215LA, M2216AP, M2217LA, M2218AP, M2219AP, M2220AP, M2221AP, M2222AP, M2223AP, M2224AP, M2225AP, M2226AP, M2227AP, M2228AP, M2229AP, M2230AP, M2231AP, M2232AP, M2233AP, M2234AP, M2235AP, M2236AP, M2237AP, M2238AP, M2239AP, M2240AP, M2241AP, M2241EA, M2242AP, M2243AP, M2244AP, M2245AP, M2245EA, M2299xx MV IUR, M2301NR, M2305NR, M2401XT, V1000, V1001AP, V1002AP, V1003AP, V1004AP, V1005AP, V1006AP, V1007AP, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP, V1023AP, V1024AP, V1025AP, V1026AP, V1027AP,	102	✗	✗



Power your laptop anywhere



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - JRM64AU	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Compaq	Presario	V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043AP, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1063AP, V1064AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1073AP, V1074AP, V1075AP, V1101AP, V1102AP, V1103AP, V1104AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1111AP, V1112AP, V1113AP, V2000, V2001AP, V2002AP, V2003AP, V2004AP, V2005AP, V2006AP, V2007AP, V2008AP, V2009AP, V2010AP, V2010US, V2011AP, V2012AP, V2013AP, V2014AP, V2015AP, V2016AP, V2017AP, V2018AP, V2019AP, V2020AP, V2021AP, V2022AP, V2024AP, V2025AP, V2026AP, V2027AP, V2028AP, V2029AP, V2030AP, V2030US, V2031AP, V2032AP, V2033AP, V2034AP, V2035AP, V2036AP, V2042AP, V2069CL, V2100, V2110US, V2135US, V2140CA, V2140US, V2205US, V2220US, V2300, V2300T, V2300Z, V2304US, V2305CA, V2305US, V2306US, V2309US, V2310CA, V2310US, V2311AP, V2311US, V2321US, V2321US, V2335US, V2398xx MV IUR, V2399xx, V2400T, V2402AU, V2403NR, V2404US, V2405CA, V2405US, V2409US, V2410CA, V2410CL, V2410US, V2413US, V2414NR, V2415LA, V2419US, V2424NR, V2552US, V2555US, V2565US, V2570CA, V2570NR, V2575US, V2582US, V2606CU, V2607CA, V2608CA, V2608WM, V2610US, V2615US, V2630US, V2658US, V2665US, V2670US, V2710CA, V2710US, V3000, V3000T, V3000Z, V3010CA, V3010US, V3015CA, V3015NR, V3018US, V3019US, V3020CA, V3020US, V3030CA, V3200, V3200TU, V3201AU, V3201TU, V3202AU, V3202TU, V3203AU, V3203TU, V3204AU, V3204TU, V3205TU, V3206TU, V3207TU, V3208TU, V3211TU, V3218TU, V3219TU, V3239AU, V3239TU, V3240AU, V3243TU, V3244TU, V3250TU, V3255TU, V3256TU, V4000, V4000xx MV IUR, V4001AP, V4002AP, V4002xx MV IUR, V4003AP, V4003xx MV IUR, V4004AP, V4004xx MV IUR, V4005CL, V4005xx, V4015US, V4020US, V4025US, V4035CA, V4035EA, V4035US, V4040EA, V4050EA, V4055EA, V4058EA, V4060EA, V4075EA, V4100, V4101AP, V4102AP, V4103AP, V4104AP, V4105AP, V4106AP, V4107AP, V4108AP, V4109AP, V4110AP, V4110EA, V4111AP, V4112AP, V4113AP, V4114AP, V4115AP, V4116AP, V4117AP, V4118AP, V4119AP, V4120EA, V4120TU, V4121TU, V4122TU, V4130EA, V4133EA, V4135US, V4144EA, V4145EA, V4146EA, V4147EA, V4160EA, V4201TU, V4202TU, V4203EA, V4205EA, V4215EA, V4240US, V4310NR, V4325CA, V4325US, V4332US, V4435NR, V4440US, V5000, V5000T, V5005CA, V5005US, V5015US, V5099xx, V5100, V5100Z, V5101US, V5102NR, V5105CA, V5105US, V5108CU, V5115US, V5119US, V5120NR, V5160US, V5200, V5201CA, V5201US, V5204NR, V5205NR, V5206OM, V5207NR, V5208CA, V5209US, V5210CA, V5210US, V5214EA, V5215EA, V5216EA, V5233EA, V5234EA, V5235EA, V5236EA, V5245EU, V5303NR, V5304US, V5305WM, V5306US, V5307US, V5308US, V5310US, V5315WM, V6000, V6000T, V6000Z, V6001AU, V6002AU, V6003AU, V6030US, V6101EU, V6101US, V6105EA, V6105NR, V6107US, V6110CA, V6110US, V6120US, V6126EU, V6130US, V6133EU, V6137US, V6205NR, V6210CA, V6210US, V6215CA, V6230CA, V6254EA, V6310US, X1000, X1001US, X1005LA, X1006EA, X1007EA, X1010AL, X1010CA, X1010EA, X1010US, X1011AL, X1012, X1012AL, X1012EA, X1012QV, X1015US, X1016EA, X1018CL, X1020EA, X1020US, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1028CL, X1029AP, X1030US, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040AP, X1040US, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP, X1050AP, X1050CA, X1050US, X1051AP, X1052AP, X1053AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1058CL, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1105EA, X1110EA, X1115EA, X1140EA, X1155EA, X1200, X1201AP, X1201US, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1210CA, X1210US, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1220EA, X1220US, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1230US, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1301US, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1324AP, X1325AP, X1326AP, X1327AP, X1328AP, X1330AP, X1360CL, X1360US, X1370US, X1390US, X1460CA, X1460US, X1480US, X1480xx, ZT3000LA	102	✗	✗
	Presario	2158AP, 2267AP, B1900, B3800, C554TU, C700T, C710TU, C731TU, C763, C774TU, M2217AP, V2649TS, V4209TU, V6107AP, B1959TU, V6201AU, V6204AU, B1201TU, B1973TU, C302TU, C310TU, C502TU, C582TU, C7xxTU, F503AU, F551AU, F573AU, V2566AP, V3118AU, V3230AU, V3307, V6107TU, V6109AU, V6150TU, V6301, V6502, V6503AU, V6508AU	102	✗	✗
	Presario	2866, 2867, 2868, 2869, 2870, 2871, 2887, 2888, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2807, 2809, 2810, 2811, 2812, 2813, 2814, 2815, 2816, 2817, 2818, 2819, 2820, 2821, 2822, 2823, 2825, 2826, 2827, 2828, 2830, 2832, 2835, 2838, 2840, 2845, 2853, 2857, 2858, 2860, 2861, 2862, 2863, 2864, 2865, 300, B1801TU, B2800, B2801-TU, B3813AP, B3827AP, C302, M2253AU, M2256AU, M2340AP, N2000, V2157AP, V2325AP, V2340AP, V2414TU, V2418AU, V2433AU, V2627AU, V3020, V3021, V4214, V4229TU, V5101AU, V5102TU, V5104AU, X1010, X1030, X1360, X1401AP, X1460, X1480, 1500 Series, 900 Series, N1050V	102	✗	T



Power your laptop anywhere



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APAG4U 90W AC/DC - APAG4U	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Compaq	Presario	B1200, 6515b, 6715b	203	✗	✗
	Presario	1232, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080US, 1200 series, 1200AN, 1200AP, 1200CA, 1200CL, 1200EA, 1200SC, 1200T-12XL, 1200TC, 1200TH, 1200US, 1201, 1201AP, 1201EA, 1201S, 1202, 1202EA, 1203, 1203CL, 1205, 1205EA, 1206R, 1207, 1210, 1210JP, 1210LA, 1211, 1211CA, 1211EA, 1211LA, 1212, 1212CL, 1212EA, 1213, 1213CL, 1213EA, 1214, 1214EA, 1214FR, 1214SR, 1215, 1216, 1216JP, 1216US, 1217, 1217JP, 1219, 1219JP, 1220, 1232ES, 1234, 1235, 1236, 1237, 1238, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1252, 1255, 1256, 1257, 1260, 1262, 1263, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 12XL, 12XL300B, 12XL400, 12XL401, 12XL404, 12XL410, 12XL420, 12XL423, 12XL426, 12XL427, 12XL430, 12XL500, 12XL501, 12XL504, 12XL505, 12XL526, 12XL527, 1400T, 14XL240, 1600, 1600 series, 1600i, 1600S, 1610, 1611, 1621, 1622, 1625, 1626, 1640, 1645, 1655, 1670, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, 16XL, 1700, 1700 series, 1700T, 1700US, 1701, 1701AK, 1702, 1702AP, 1703, 1703KR, 1704, 1704KR, 1705, 1705AP, 1710, 1710T, 1711, 1711CL, 1712, 1712US, 1713, 1713EA, 1714, 1714EA, 1715, 1715EA, 1716, 1716EA, 1717, 1717RSH, 1720, 1721, 1721EA, 1722, 1722US, 1723, 1723AP, 1724, 1724TC, 1725, 1725TC, 1726, 1726TC, 17XL260, 1800t, 1800US, 1800XL180, 18XL280, 2700, 2700 series, 2700T, 2700TC, 2700US, 2700xx, 2701, 2701TW, 2701US, 2702, 2702EA, 2710, 2710CA, 2710EA, 2710SC, 2710TC, 2710US, 2711, 2711AP, 2711EA, 2711TC, 2712, 2712EA, 2715, 2715EA, 2715US, 2716, 2716EA, 2720, 2720US, 700, 700 series, 700US, 701, 701CL, 702, 702US, 703, 703AP, 704, 704JP, 705, 705US, 706, 706EA, 709, 709EA, 710, 710TC, 711, 711EA, 712, 712EA, 713, 713EA, 714, 714EA, 715, 715US, 716, 716EA, 717, 717RSH, 718, 718EA, 719, 719EA, 720, 720US, 721, 721EA, 722, 722EA, 723, 723EA, 724, 724EA, 725, 725EA, 726, 726EA, 727, 727EA, 728, 728EA, 729, 729EA, 730, 730CA, 731, 731US, 732, 732US, 733, 734, 734RSH, 735, 735CA, 736, 737, 737EA, 738, 738EA, 739, 739EA, 800T, 801, 802, 803, 850, 1080, 1115, 1120, 1400, 1450, 14XL, 17XL, 1800, 18XL, 2100 series, 2500 series, 2505EA, 2510EA, 2520EA, 2528EA, 2558EA, 3000, 3005, 3015, 3017, 3019, 3020, 3080, 71110, 800, X1001	206	✗	P
	Presario	1501AP, 1501CL, 1502LA, 1503AP, 1504AP, 1505US, 1506AP, 1507AP, 1508AP, 1509AP, 1510AP, 1510CA, 1510TC, 1510US, 1511AP, 1512AP, 1514AP, 1520AP, 1520CA, 1520LA, 1520US, 1522AP, 1522EA, 1522LA, 1523EA, 1525AP, 1525CA, 1525EA, 1525US, 1527EA, 1528AP, 1528CL, 1530SC, 1531AP, 1532AP, 1535AP, 1536AP, 1538AP, 1540AP, 1545AP, 1550AP, 1555AP, 1565AP, 1570AP, 1572AP, 1575AP, 1580AP, 901EA, 902EA, 903EA, 904RSH, 905LA, 905US, 906US, 907EA, 908EA, 909EA, 910AP, 910EA, 910US, 911DE, 912EA, 912RSH, 914EA, 915CA, 915EA, 915US, 916US, 917DE, 917EA, 918RSH, 919EA, 920AP, 920CA, 920EA, 920LA, 920US, 921AP, 922UK, 923AP, 925AP, 925EA, 927AP, 930AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP, M2050AP	201	✗	✗
	Prosignia	170, 190	102	✗	✗
	Prosignia	150	206	✗	P
	Tablet	TC-1000, TC-1100	102	✗	T
Dell	Inspiron	1501, 300M, 500M, 510M, 5160, 6000, 600M, 630M, 700M, 710M, 1420, 1520, 1521, 1720, 1721, 1150, 6400, 8500, 8600, 9200, 9300, 9400, E1505, E1705, 640m, E1405	202	✗	✗
	Inspiron	1200, 1300, 2200, 3000, 3200, 3500, 7000, B120, B130	206	✗	P
	Inspiron	2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100	✗	✗	S
	Latitude	131L, ATG, D400, D410, D420, D430, D500, D505, D510, D520, D600, D610, D630(Intel Graphic Card), X1, X300, D620, D630(NVidia Graphic Card), D800, D810, D820, L100	202	✗	✗
	Latitude	110L	206	✗	P
	Latitude	C400, C410, C500, C510, C600, C610, C800, C810, CP, CPi, CPt, CPx, CS/CSx, LM, X200, C640	✗	✗	S
	Precision	M20, M60, M65, M70	202	✗	✗
	Vostro	1000, 1400, 1500, 1700	202	✗	✗
XPS	M1210, M1330 (Intel graphic card), M140, M1330 (NVidia graphic card)	202	✗	✗	

Power your laptop anywhere



AC wall



DC auto



DC air



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - AP64AU	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Fujitsu	Amilo Pro	V2000D, V8010D	207	✗	T
	FMV-BIBLO	FLX2H, LOOX S80B, LOOX S80B/W, LOOX S80C, LOOX S80C/W, LOOX T50E, LOOX T50E/W, LOOX T50G/W, LOOX T50H, LOOX T50J, LOOX T50K, LOOX T55G, LOOX T70E, LOOX T70G, LOOX T70H, LOOX T70HN, LOOX T70J, LOOX T70JN, LOOX T70K/T, LOOX T93B, LOOX T93B/W, LOOX T93C, LOOX T93C/W, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG50G, MG50H, MG50HN, MG50K, MG50K/T, MG55E, MG70E, MG70E/ST, MG70G, MG70G/ST, MG70H, MG70K/T, MG75E, MG75G, MG75H, MG75H/ST, MG75HN, MG75K, MR16B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/A, NB16C/R, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB50E, NB50G, NB50H, NB50HN, NB50J, NB50JN, NB50K, NB53E, NB55E, NB55E/T, NB55G, NB55G/T, NB55H, NB55H/T, NB55J, NB55J/T, NB55K, NB55K/T, NB70E, NB70E/T, NB70G, NB70H/T, NB75G, NB75G/T, NB75H, NB75H/T, NB75HN, NB75HN/T, NB75J, NB75K/T, NB80J, NB80JN, NB80K, NB90J/T, NB90J/TS, NB90JN/T, NB90K/T, NB90K/TS, NB90KN/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T	✗	N	✗
	LifeBook	200, 400, 420Dx, 535T, 555Tx, 600, 656Tx1, 700, 900, B5010, B6110D, B6210, Celsius Mobile H, E330, E335, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, P1510D, P1610, P7120, P7120D, P7230, Q2010, S2110, S6230, S6240, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, Stylistic 3400, Stylistic 3500, Stylistic CT2020, Stylistic LT C500, Stylistic LT P600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120P, Stylistic ST4121P, Stylistic ST5010, Stylistic ST5010D, Stylistic ST5011, Stylistic ST5011D, Stylistic ST5020, Stylistic ST5020D, Stylistic ST5021, Stylistic ST5021D, Stylistic ST5022, Stylistic ST5022D, 270Dx, 280Dx, 420D, 435Dx, 500, 520D, 520T, 530T, 531T, 535Tx, 555T, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B245x, B2545, B2562, B2566, B256x, B2610, B2620, B2630, B3010D, B3020, B3020D, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651, C7631, C7651, C7661, Exxx5, L440, L470, P1000, P1032, P1035, P1110, P1120, P2000, P2040, P2046, P2110, P2120, P5010, P5010D, P5020, P5020D, P7010, P7010D, S2010, S2020, S4510, S4542, S4546, S4572, S5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6231, T3010, T3010D	✗	N	✗
	LifeBook	Amilo L, C1211D, C2320, C2330, C3367, C6637, E4010D, E6624, E6634, E6644, E6654, E6664, E7010, E7110, E8010D, E8020, S6130, S7011, S7110, Stylistic ST4120, Stylistic ST4121, C1410, C2340, E8020D, N6210, N6220, T4020, A1010, C1010, C1020, C1110, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2340, C6xx7, E2010, E8010, S7010, S7010D, T4010, T4010D, T4020, A3110, E8020, E8110, E8210, N3510, N3511, N3520, N3530, N6110, S6410, T4210, T4220	206	✗	P
LifeBook	E4010, E66xx	206	✗	✗	
Gateway	Gateway	400SD4, 400VTX, 4012GZ, 4024GZ, 4026GZ, 4028GZ, 405E, 405X, 450ROG, 450SX4, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 600YG2, 600YGR, M305, M500	206	✗	P
	Solo	1100 Series, 1150, 1200, 1400, 1450, 2100 series, 2150 Series, 2200 series, 2300 series, 2500 series, 2550 Series, 3100 Series, 3150 Series, 5100 series, 5150 Series, 5300, 5350, 9100 Series, 9150, 9300 Series, 9500, 9550	206	✗	P
HP	Business Tablet	TC4200	102	✗	✗
	Business Thin Client	2533t, 6720t	203	✗	✗
	Elitebook	2530p, 2730p, 6930p	203	✗	✗
	HP	530	102	✗	✗
	HP Compaq Business	6720s, NC6220, NX5000	102	✗	✗
	HP Compaq Business	2230s, 2510p, 2710p, 6710s, 6735s, NC4400, NC6320, NX6320, NX6325, NX7300, NX7400, 6510b, 6530b, 6531s, 6535b, 6710b, 6712b, 6730b, 6730s, 6735b, 6830s, 6910p, NC2400, NC4200, NC6000, NC6400, NC6440, NC8000, NC8230, NC8430, NW8000, NW8240, NX7010, NX8220, 8510p, 8510w	203	✗	✗
	HP Compaq Business	6520s, 6820s, NX6120	201	✗	✗
	Mini-Note	2133	203	✗	✗
Omnibook	2000, 2100, 2103, 2105, 300, 3000, 3100, 3101, 4000, 4000C, 4100, 4101, 4103, 4105, 4150, 4150B, 425, 430, 500, 5000, 510, 530, 5500, 5700, 6000, 6000B, 6000C, 6100, 7100, 7103, 7150, 900, 900B, N3000, VT6200, XE, XE2, XE2-DB, XE2-DC, XE2-DD, XE2-DE, XE2-DI, XE3, XE3B, XE3C, XE3-GD, XE3-GF, XE4100, XE4200, XE4500, XE-DA, XT1000, XT1500, XT6050, XT6200, XE 4400 BTO, XE4400	206	✗	P	



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - AP64AU	75W AC	90W AC
	Tip	Tip

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	4316, 4523, 3010AP, V5022AP, ZE5526AP, ZT3050AP, ZT3301AP, ZV5203AP, 3011AP, 6100 Series, DV1000, DV1001AP, DV1002AP, DV1003AP, DV1004AP, DV1005AP, DV1005EA, DV1006AP, DV1007AP, DV1008AP, DV1009AP, DV1010AP, DV1010CA, DV1010US, DV1012LA, DV1013AP, DV1014AP, DV1014LA, DV1015AP, DV1015LA, DV1016AP, DV1017AP, DV1018AP, DV1019AP, DV1019EA, DV101EAP, DV1020AP, DV1021AP, DV1022AP, DV1023AP, DV1024AP, DV1024LA, DV1025AP, DV1025LA, DV1026AP, DV1027AP, DV1029AP, DV1030AP, DV1031AP, DV1040CA, DV1040US, DV1044LA, DV1045EA, DV1045LA, DV1049CL, DV1049EA, DV1050EA, DV1055EA, DV1060US, DV1064EA, DV1065EA, DV1065US, DV1066EA, DV1067EA, DV1075EA, DV1100, DV1101AP, DV1102AP, DV1103AP, DV1104AP, DV1105AP, DV1105EA, DV1106AP, DV1107AP, DV1107EA, DV1108AP, DV1109AP, DV1109EA, DV1110AP, DV1110EA, DV1111AP, DV1111EA, DV1112AP, DV1112EA, DV1113AP, DV1115AP, DV1115LA, DV1116AP, DV1117AP, DV1118AP, DV1119AP, DV1120AP, DV1121AP, DV1122AP, DV1123AP, DV1124AP, DV1125AP, DV1125EA, DV1125LA, DV1127AP, DV1128AP, DV1129AP, DV1130AP, DV1130CA, DV1130EA, DV1130US, DV1131AP, DV1131EA, DV1132AP, DV1133AP, DV1133WMM, DV1134AP, DV1135AP, DV1135EA, DV1135LA, DV1136AP, DV1136EA, DV1137AP, DV1137EA, DV1138EA, DV1139AP, DV1139EA, DV1140EA, DV1142EA, DV1145EA, DV1150US, DV1152EA, DV1153EA, DV1154EA, DV1155EA, DV1156CL, DV1159EA, DV1160EA, DV1165EA, DV1167EA, DV1168EA, DV1170CA, DV1170EA, DV1170US, DV1175US, DV1180EA, DV1180US, DV1190EA, DV1207US, DV1210US, DV1217US, DV1220EA, DV1220US, DV1224EA, DV1225EA, DV1227US, DV1230EA, DV1240CA, DV1240US, DV1245EA, DV1249EA, DV1250EA, DV1251EA, DV1252EA, DV1253EA, DV1254EA, DV1255EA, DV1258EA, DV1259EA, DV1260EA, DV1262EA, DV1263EA, DV1265EA, DV1266EA, DV1267EA, DV1270EA, DV1272EA, DV1275EA, DV1280EA, DV1281EA, DV1300, DV1301XX MV IUR, DV1302XX MV IUR, DV1310US, DV1311AP, DV1311SE, DV1312AP, DV1313AP, DV1314AP, DV1315AP, DV1315CL, DV1315LA, DV1316AP, DV1317AP, DV1317LA, DV1318AP, DV1319AP, DV1320AP, DV1320BR, DV1320US, DV1321AP, DV1321US, DV1324AP, DV1325AP, DV1325EA, DV1325LA, DV1326AP, DV1326EA, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1330BR, DV1330CA, DV1331AP, DV1331EA, DV1331SE, DV1332AP, DV1332EA, DV1333AP, DV1333EA, DV1334AP, DV1335AP, DV1335LA, DV1336AP, DV1338AP, DV1339AP, DV1340AP, DV1340BR, DV1340US, DV1341AP, DV1342AP, DV1343AP, DV1344AP, DV1345AP, DV1345EA, DV1346AP, DV1347AP, DV1348AP, DV1349AP, DV1350AP, DV1350EA, DV1351AP, DV1351EA, DV1352AP, DV1352EA, DV1353AP, DV1353EA, DV1354AP, DV1354EA, DV1355AP, DV1355EA, DV1356AP, DV1356EA, DV1357AP, DV1358AP, DV1358EA, DV1359AP, DV1359EA, DV1360AP, DV1361AP, DV1362AP, DV1362EA, DV1362TU, DV1363AP, DV1363EA, DV1364AP, DV1365AP, DV1365EA, DV1366AP, DV1366EA, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375EA, DV1375TU, DV1376TU, DV1379TU, DV1380TU, DV1381TU, DV1382TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1389TU, DV1390TU, DV1391TU, DV1392TU, DV1393TU, DV1394TU, DV1395TU, DV1396TU, DV1399XX MV IUR, DV1410US, DV1411SE, DV1420CA, DV1420US, DV1427US, DV1430US, DV1432US, DV1439CA, DV1439US, DV1440CA, DV1440US, DV1510US, DV1515CL, DV1519US, DV1520CA, DV1520US, DV1530CA, DV1530US, DV1532US, DV1550SE, DV1580SE, DV1600, DV1610TN, DV1610US, DV1620US, DV1624NR, DV1629US, DV1648US, DV1650US, DV1656US, DV1658US, DV1659US, DV1660SE, DV1670US, DV1680CA, DV1680US, DV1688US, DV1708NR, DV1738OD, DV2000, DV2000Z, DV2002TU, DV2015NR, DV2017TU, DV2020CA, DV2020US, DV2023, DV2023TU, DV2025NR, DV2029EA, DV2029TU, DV2035US, DV2036EA, DV2036TU, DV2037US, DV2040CA, DV2040US, DV2045EA, DV2045TU, DV2047CL, DV2050US, DV2054EA, DV2104EA, DV2104EU, DV2111TX, DV2112TX, DV2120US, DV2125NR, DV2130US, DV2133, DV2205EA, DV2210US, DV2214US, DV2220US, DV2221US, DV2225NR, DV2275EA, DV2310US, DV2315NR, DV2401TU, DV2402TU, DV2403TU, DV2404TU, DV2405TU, DV4000xx MV IUR, DV4001AP, DV4001EA, DV4001xx MV IUR, DV4002AP, DV4003AP, DV4004AP, DV4004xx MV IUR, DV4005AP, DV4005US, DV4005xx MV IUR, DV4006AP, DV4006xx MV IUR, DV4007AP, DV4007xx MV IUR, DV4008AP, DV4009AP, DV4010AP, DV4011AP, DV4012AP, DV4013AP, DV4014AP, DV4014EA, DV4015AP, DV4015CL, DV4015EA, DV4016AP, DV4016EA, DV4017AP, DV4017EA, DV4018AP, DV4018CL, DV4018EA, DV4019AP, DV4019EA, DV4020AP, DV4020EA, DV4020US, DV4021AP, DV4021EA, DV4022AP, DV4022EA, DV4023AP, DV4023EA, DV4024AP, DV4024EA, DV4025AP, DV4025EA, DV4026AP, DV4027EA, DV4029EA, DV4030CA, DV4030EA, DV4030US, DV4031EA, DV4037EA, DV4040CA, DV4040EA, DV4040US, DV4043EA, DV4045EA, DV4046EA, DV4049EA, DV4050EA, DV4051EA, DV4052EA, DV4054EA, DV4056EA, DV4057EA, DV4060EA, DV4070EA, DV4073EA, DV4075EA, DV4078EA, DV4080EA, DV4085EA, DV4086EA, DV4100, DV4102EA, DV4103EA, DV4108EA, DV4109EA, DV4110EA, DV4113EA, DV4114, DV4115EA, DV4117AP, DV4121AP, DV4122EA, DV4124EA, DV4125EA, DV4125US, DV4126AP, DV4126EA, DV4128EA, DV4129EA, DV4130EA, DV4130US, DV4131EA, DV4134EA, DV4135EA, DV4136EA, DV4137EA, DV4138EA, DV4139EA, DV4140EA, DV4141EA, DV4142EA, DV4143EA, DV4144EA, DV4145EA, DV4146EA, DV4148EA, DV4149EA, DV4150EA, DV4150US, DV4151EA, DV4152EA, DV4153EA, DV4154EA, DV4155EA, DV4156EA, DV4157EA, DV4158EA, DV4159EA, DV4160EA, DV4161EA, DV4162EA, DV4163EA, DV4164EA, DV4165CL, DV4165EA, DV4170US, DV4174EA, DV4176EA, DV4178EA, DV4182EA, DV4199EA, DV4201TU, DV4201TX, DV4202TU, DV4202TX, DV4203EA, DV4203TU, DV4203TX, DV4204TU, DV4204TX, DV4205TX, DV4206TU, DV4206TX, DV4207EA, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4216TX, DV4217CL, DV4217TX, DV4218TX, DV4219TX, DV4220TX, DV4221TX, DV4222TX, DV4223CL, DV4223EA, DV4223TX, DV4224TX, DV4225EA, DV4225NR, DV4225TX, DV4226EA, DV4227EA, DV4230US, DV4232EA, DV4234EA, DV4235EA, DV4236EA, DV4241EA, DV4243EA, DV4245EA, DV4246EA, DV4250EA, DV4250US, DV4251EA, DV4253EA, DV4253US, DV4254EA, DV4257US, DV4261EA, DV4264EA, DV4266EA, DV4268EA, DV4269EA, DV4269US, DV4270CA, DV4270EA, DV4270US, DV4271EA, DV4272EA, DV4272US, DV4273EA, DV4275EA, DV4275NR, DV4276EA, DV4277EA, DV4280EA, DV4282EA, DV4283EA,	102	x	x



Power your laptop anywhere



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - #P64AU	75W AC	90W AC	
90W AC/DC - #R64AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	DV4284EA, DV4285EA, DV4287EA, DV4288, DV4288EA, DV4289EA, DV4290EA, DV4291EA, DV4294EA, DV4295EA, DV4296EA, DV4305US, DV4307CA, DV4307CL, DV4308WM, DV4310US, DV4320US, DV4330CA, DV4330US, DV4335US, DV4340CA, DV4340US, DV4401RS, DV4405NR, DV4419US, DV4420, DV4420CA, DV4420US, DV4935WM, DV5000, DV5000T, DV5020US, DV5029US, DV5030US, DV5035NR, DV5040US, DV5100, DV5101TU, DV5101TX, DV5102TU, DV5102TX, DV5103TX, DV5104TU, DV5104TX, DV5105TX, DV5107TX, DV5108TX, DV5109TX, DV5110EU, DV5110TX, DV5110US, DV5112TX, DV5113TX, DV5114TX, DV5115NR, DV5115TX, DV5116NR, DV5116TX, DV5117CA, DV5117TX, DV5118TX, DV5120EA, DV5120LA, DV5120TX, DV5120US, DV5121EA, DV5121TX, DV5122EA, DV5123EA, DV5123TX, DV5124TX, DV5125EU, DV5125TX, DV5126EA, DV5126TX, DV5127EA, DV5127TX, DV5128EA, DV5128TX, DV5129TX, DV5129US, DV5130EA, DV5130TX, DV5130US, DV5131TX, DV5133EA, DV5134EA, DV5135NR, DV5137EA, DV5139US, DV5140EA, DV5140US, DV5142EA, DV5143EA, DV5144EA, DV5145EA, DV5147EA, DV5148EA, DV5149EA, DV5150EA, DV5150US, DV5156EA, DV5157EA, DV5158EA, DV5159EA, DV5160EA, DV5161EA, DV5162EA, DV5164EA, DV5165EA, DV5166EA, DV5170US, DV5173EA, DV5175EA, DV5176EA, DV5177EA, DV5178EA, DV5178US, DV5179EA, DV5180EA, DV5184EA, DV5188EA, DV5190EA, DV5191EA, DV5192EA, DV5193EA, DV5194EA, DV5195EA, DV5196EA, DV5196XX, DV5197EA, DV5197XX, DV5200, DV5200TU, DV5200TX, DV5201EU, DV5201TU, DV5201TX, DV5202TU, DV5202TX, DV5203EA, DV5203TU, DV5203TX, DV5204EA, DV5204TU, DV5204TX, DV5205EA, DV5205TX, DV5206TU, DV5206TX, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210CA, DV5210TX, DV5210US, DV5211EA, DV5211TX, DV5212EA, DV5212TX, DV5213TX, DV5214TX, DV5215CA, DV5215TX, DV5215US, DV5216TX, DV5217TX, DV5218EA, DV5218NR, DV5218TX, DV5219TX, DV5220CA, DV5220LA, DV5220TX, DV5220US, DV5221TX, DV5222NR, DV5222TX, DV5223OM, DV5223TX, DV5224EA, DV5224NR, DV5224TX, DV5225EA, DV5225TX, DV5226CA, DV5226EU, DV5226TX, DV5227TX, DV5228TX, DV5229OM, DV5229TX, DV5230CA, DV5230TX, DV5231TX, DV5232EU, DV5232TX, DV5233EA, DV5233TX, DV5234EA, DV5234US, DV5235CA, DV5235EA, DV5235TX, DV5236EA, DV5236EU, DV5236OM, DV5236TX, DV5237CL, DV5237EA, DV5237TX, DV5240CA, DV5240EA, DV5241EA, DV5242EA, DV5243EA, DV5244EA, DV5245EA, DV5247EA, DV5248EA, DV5249EA, DV5250CA, DV5250EA, DV5250US, DV5261EA, DV5264EA, DV5266EA, DV5267EA, DV5274EA, DV5275EA, DV5276EA, DV5276EU, DV5277EA, DV5279EU, DV5280EA, DV5282EA, DV5284EA, DV5285EA, DV5287EA, DV5289EA, DV5292EA, DV5293EA, DV5294EA, DV5295EA, DV5296EA, DV5298EA, DV6010EA, DV6011EA, DV6023EA, DV6101EU, DV6102OD, DV6103NR, DV6104EU, DV6105US, DV6107US, DV6109OM, DV6110US, DV6113US, DV6115CA, DV6115EU, DV6116EU, DV6119US, DV6122EA, DV6124EA, DV6125SE, DV6126EU, DV6128TU, DV6129US, DV6130US, DV6131OD, DV6133EU, DV6135EU, DV6135NR, DV6139US, DV6140US, DV6152EU, DV6153EU, DV6190EU, DV6200, DV6204AU, DV6205CA, DV6206US, DV6208NR, DV6213CL, DV6215CA, DV6215US, DV6219US, DV6225US, DV6226US, DV6227CL, DV6231EU, DV6233SE, DV6235CA, DV6235NR, DV6235US, DV6236US, DV6238EA, DV6243CL-B, DV6244EU, DV6244US, DV6245CA, DV6245US, DV6247CA, DV6247CL, DV6253CL, DV6255CA, DV6255US, DV6256US, DV6258SE, DV6262EU, DV6263CL, DV6265CA, DV6265US, DV6267CL-B, DV6277EA, DV6299EA, DV6305CA, DV6308NR, DV6325CA, DV6326US, DV6335CA, DV6335US, DV6337CL, DV6337US, DV6338SE, DV6345US, DV6358SE, DV6363CA, DV6365US, DV8000xx, DV8002EA, DV8005EA, DV8013CL, DV8013xx, DV8026EA, DV8027EA, DV8029EA, DV8030EA, DV8035EA, DV8040CA, DV8040US, DV8040xx, DV8050EA, DV8051EA, DV8088US, DV8099xx, DV8110US, DV8125NR, DV8130US, DV8135NR, DV8140US, DV8200, DV8210US, DV8218, DV8219, DV8220US, DV8225NR, DV8240US, DV8301NR, DV8305CA, DV8305US, DV8308, DV8309US, DV8310TX, DV8310US, DV8315NR, HDX9003TX, HDX9004TX, TX1000, TX1001AU, TX1001xx, TX1002AU, TX1002xx, TX1003AU, TX1003xx, TX1004AU, TX1005AU, TX1006AU, TX1007AU, TX1008AU, TX1020EA, TX1030EA, TX1030IA, TX1040EA, TX1080EA, TX1110US, TX1120US, TX2011AU, ZE2001AP, ZE2001EA, ZE2001xxMV IUR, ZE2002AP, ZE2002EA, ZE2003AP, ZE2004AP, ZE2004US, ZE2005AP, ZE2005EA, ZE2006AP, ZE2007AP, ZE2007EA, ZE2008AP, ZE2008WM, ZE2009AP, ZE2009xxMV IUR, ZE2010AP, ZE2010BR, ZE2010EA, ZE2011AP, ZE2012AP, ZE2013AP, ZE2014AP, ZE2015AP, ZE2015EA, ZE2015US, ZE2016AP, ZE2017AP, ZE2018AP, ZE2019AP, ZE2020AP, ZE2020BR, ZE2020CA, ZE2020EA, ZE2021EA, ZE2022EA, ZE2023EA, ZE2024EA, ZE2025EA, ZE2026EA, ZE2027EA, ZE2028EA, ZE2030BR, ZE2039EA, ZE2040BR, ZE2040EA, ZE2044EA, ZE2045EA, ZE2050EA, ZE2055EA, ZE2058EA, ZE2060EA, ZE2062EA, ZE2064EA, ZE2065EA, ZE2068EA, ZE2070EA, ZE2090EA, ZE2091EA, ZE2101EA, ZE2104EA, ZE2105EA, ZE2108EA, ZE2108WM, ZE2109EA, ZE2110EA, ZE2111EA, ZE2112EA, ZE2113EA, ZE2113US, ZE2114EA, ZE2114US, ZE2115US, ZE2117EA, ZE2117US, ZE2120CA, ZE2125EA, ZE2128EA, ZE2129EA, ZE2130EA, ZE2140EA, ZE2150EA, ZE2151EA, ZE2200, ZE2200T, ZE2200Z, ZE2201AP, ZE2201xxMV IUR, ZE2202AP, ZE2203AP, ZE2204AP, ZE2204EA, ZE2205AP, ZE2205EA, ZE2206AP, ZE2206EA, ZE2207AP, ZE2208AP, ZE2209AP, ZE2209xxMV IUR, ZE2210AP, ZE2211AP, ZE2212AP, ZE2215EA, ZE2216EA, ZE2220LA, ZE2221EA, ZE2225EA, ZE2240EA, ZE2241EA, ZE2242EA, ZE2247EA, ZE2250EA, ZE2251EA, ZE2260EA, ZE2262EA, ZE2265EA, ZE2275EA, ZE2281EA, ZE2285EA, ZE2296xxMV IUR, ZE2297xxMV IUR, ZE2298xxMV IUR, ZE2299xxMV IUR, ZE2308WM, ZE2309NR, ZE2315US, ZE2401XT, ZE4901 MV IUR, ZE4901EA, ZE4901US, ZE4902 MV IUR, ZE4902EA, ZE4903US, ZE4904EA, ZE4904US, ZE4905EA, ZE4906US, ZE4907WM-B, ZE4908US, ZE4910EA, ZE4910US, ZE4911EA, ZE4911US, ZE4912EA, ZE4913EA, ZE4914EA, ZE4915EA, ZE4916EA, ZE4919CL, ZE4920EA, ZE4921EA, ZE4927EA, ZE4928EA, ZE4929EA, ZE4930EA, ZE4930EA, ZE4931EA, ZE4933EA, ZE4933EA, ZE4934EA, ZE4935WM, ZE4938EA, ZE4938EA, ZE4940EA, ZE4941US, ZE4942US, ZE4947WM-B, ZE4949US, ZE4950EA, ZT3000, ZT3001US, ZT3010, ZT3010AP, ZT3010EA, ZT3010US, ZT3011AP, ZT3012AP, ZT3012EA, ZT3013AP, ZT3014AP, ZT3015AP, ZT3015EA, ZT3016AP, ZT3017AP, ZT3017EA, ZT3017LA, ZT3017WM, ZT3018AP, ZT3019AP, ZT3019EA, ZT3020, ZT3020AP, ZT3020EA, ZT3020US, ZT3021AP, ZT3022AP, ZT3022EA, ZT3023AP, ZT3024AP, ZT3024EA, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3030EA,	102	x	x



Power your laptop anywhere



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models – they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC	90W AC	
90W AC/DC - AP64AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3050EA, ZT3051AP, ZT3057LA, ZT3068CL, ZT3101EA, ZT3101US, ZT3105EA, ZT3106EA, ZT3110EA, ZT3111EA, ZT3113EA, ZT3114EA, ZT3115EA, ZT3116EA, ZT3120EA, ZT3130EA, ZT3131EA, ZT3140US, ZT3170US, ZT3201AP, ZT3201US, ZT3202AP, ZT3203AP, ZT3204AP, ZT3205AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3210AP, ZT3210EA, ZT3211AP, ZT3212AP, ZT3215EA, ZT3239EA, ZT3250US, ZT3250xx, ZT3280, ZT3302, ZT3302US, ZT3340, ZT3340US, ZT3349CL, ZT3350, ZT3350US, ZT3355US, ZT3380, ZT3380US	102	✗	✗
	Pavillion	2105, 2105US, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTCCO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT115, XT118, XT118, XT125, XT128, XT155, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT5377, XT545, XT555, XT565, XT575, XT585, XT595, XU/ZU BTCCO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4133, ZE4135, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE4211, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4315US, ZE4316, ZE4317, ZE4318, ZE4319, ZE4320, ZE4321, ZE4323, ZE4325, ZE4325US, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4345, ZE4347, ZE4348, ZE4349, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE4386, ZE5715CA, ZT1000-IB BTCCO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU1155, ZU1175, ZU175, XT178, XT183, XT4316WM, XT4345QV, XT512, XT5300, XT5335QV, XT5366, XT5366WM, XT5377QV, XT5477WM	206	✗	P
	Pavillion	DV2040TX, DV2222TX, DV6207TX, DV6218TX, DV6221TX, DV9203TX, DV9205TX, DV9303TX, DV2000T, DV2024TX, DV2085, DV2113TU, DV2123TU, DV2305TU, DV2308TX, DV2533TX, DV2609TX, DV2632TX, DV2633TX, DV2637TX, DV2754TX, DV4000, DV6000, DV6000Z, DV6001EA, DV6001XX, DV6003EA, DV6004EA, DV6005EA, DV6006EA, DV6007EA, DV6013EA, DV6014EA, DV6015EA, DV6016EA, DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA, DV6058CL, DV6058EA, DV6059EA, DV6060EA, DV6061US, DV6062EA, DV6063EA, DV6065EA, DV6067EA, DV6086EA, DV6087EA, DV6088EA, DV6095EA, DV6097EA, DV6108NR, DV6113TX, DV6116EA, DV6116TX, DV6118EA, DV6120US, DV6121TX, DV6122TX, DV6129TX, DV6130EU, DV6140EU, DV6142EA, DV6146EU, DV6148EA, DV6149US, DV6150EA, DV6150US, DV6152EA, DV6155EA, DV6156EU, DV6157EA, DV6162EA, DV6174CL, DV6174EA, DV6184EU, DV6201TU, DV6205US, DV6275US, DV6285EU, DV6295EU, DV6302TU, DV6304TX, DV6306TX, DV6375US, DV6404TU, DV6500, DV6505TU, DV6519TX, DV6521TX, DV6528TX, DV6547TX, DV6601AX, DV6614TX, DV6617TX, DV6709AX, DV6721TX, DV6724TX, DV6733TX, DV6746TX, DV6755TX, DV6757TX, DV6796TX, DV6835, DV6837TX, DV6838TX, DV8000, DV9000, DV9000T, DV9000Z, DV9001EA, DV9001xx, DV9003xx, DV9005EA, DV9005US, DV9006EA, DV9007, DV9007TX, DV9008NR, DV9008TX, DV9009NR, DV9010US, DV9015EA, DV9018, DV9018TX, DV9022EA, DV9023US, DV9024EA, DV9030EA, DV9030US, DV9033CL, DV9035NR, DV9036EA, DV9037EA, DV9040EA, DV9040US, DV9042EA, DV9043EA, DV9044EA, DV9047EA, DV9050EA, DV9051EA, DV9053EA, DV9054EA, DV9056EA, DV9057EA, DV9060US, DV9061EA, DV9065EA, DV9074EA, DV9075EU, DV9076EA, DV9079, DV9083EA, DV9088EA, DV9089EA, DV9091EA, DV9092EA, DV9093EU, DV9095EA, DV9095xx, DV9096EA, DV9098xx, DV9205US, DV9206EU, DV9208NR, DV9210US, DV9218TX, DV9220US, DV9230US, DV9233EU, DV9235NR, DV9260NR, DV9260US, DV9267EA, DV9288EA, DV9289EA, DV9292EU, DV9299EA, DV9307TX, DV9308NR, DV9330US, DV9398EA, DV9410US, DV9501TX, DV9518TX, DV9520TX, DV9521TX, DV9613TX, DV9615TX, DV9700, DV9722TX, DV9724TX, DV9725TX, DV9748TX, DV9822TX, TX1219AU	201	✗	✗
	Pavillion	DV5-1009TX, DV4-10041TX, DV4-1004TU, DV-1048TX, DV4-1049TX, DV5-1004TX, DV5-1007TX, DV5-1045TX, DV5-1046TX, DV5-1050TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV71002TX, DV7-1026TX	203	✗	✗



Power your laptop anywhere



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP6A4AU 90W AC/DC - AP6B4AU	75W AC	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
IBM/ Lenovo	3000	C100, C200, C205, N100, V100	204	✗	R
	ThinkPad	X60, X60 Tablet, X60s, Z61e, Z61m, Z61t, G50, R60, R60e, R61, R61e, R61i, T60, T60p, T61p, X61, X61t, Z60m, Z60t, Z61p	204	✗	R
	ThinkPad	240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20m, A20p, A21, A21e, A21m, A21p, A22, A22e, A22m, A22p, A30, A30p, A31, A31p, A50, A50p, A51p, i1200, i1300, i1400-2621, i1500-2621, i1720, i1721, R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52, T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p, TransNote, X Series Tablet, X20, X21, X22, X23, X24, X30, X31, X32, X40, X41, X41 Tablet	104	P	✗
	ThinkPad	1400-2611, 1500-2611, 310, 310D, 310E, 310ED	206	✗	✗
LG	F1	F1-2224A, F1-2226A	201	✗	T
	LE Series	LE50-5	201	✗	T
	LM Series	LM50	201	✗	T
	LS Express	LS55, LS70	207	✗	T
	LS Series	LS70-FLA4PA	201	✗	T
	LS Series	LS50-1, LS50-2, LS50-3, LS50-4, LS50-5, LS50-UK2A, LU-20 Tablet	207	✗	T
	LT Series	LT19	207	✗	T
	LW Series	LW20-22, LW40, LW60, LW65, LW70, LW75, LW80	201	✗	T
	P1	P1, P1-52A7A, P1-J101A, P1-J102A, P1-J226A, P1-J2A8A, P1-J2B8A, P1-J5C6A, P1-J7P1A, P1-JUWSA, P1-JWS1A, P1-JWS2A, P1-KB10A, P1-KB11A, P1-KB20A	201	✗	T
S1	S1-P723A	201	✗	T	
Macron		M363C, M540G, M540N, M550G, M550N, M551N, NW120, NW150, NX150	104	P	✗
NEC	LaVie	C Series, F Series, G Series, J Series, L Series, M Series, ME Series, N Series, Pro Series, T Series	206	✗	P
	Pocket Gear	MC/PG5000, MC/PG7000	206	✗	P
	Ready	220T, 230T, 330T, 340T, 360T, 440T	206	✗	P
	Versa	E6210-1604DR, E6210-1810DR, E6210-1811DR, 2400, 2500, 2500CD, 2505, 2530, 4000 Series, 4000C, 4000D, 4000Hs, 4050C, 4050D, 4050H, 4080H, 4200, 4230, 500, 5000, 5060, 5060X, 5080, 5080X, 550D, A2100, C140, C150, C160, E120, E200, E2000, E3100, E3100-1812DW, E3100-1813DR, E600, E6000, E6000X, E6200, E6200-1703DR, E6210, E6210-1627DR, E6210-1809DR, E6300, E6300-1504DR, E6300-1803DR, E6300-2201DR, E6310, E6310-2000DR, E680, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L2100, L2100-1605DR, L2100-1606DR, L2100-1803DR, L2200-1802DR, L320, M300, M320, M3210, M440, M450, M500, M54, M540, P440, P520, P600, P700, P7200, P7200-1607DR, P7200-1800DR, P9110, P9110-1500DR, P9110-1800DR, P9110-2203DR, Premium, S1100, S800, S820, S940, S970, T400, T400S820, VersaNote, VX	206	✗	P
	Versa	2000C, 6000, 6000H, 6010H, 6030H, 6030X, 6050 Series, 6050MH, 6050MT, 6050MX, 6060, 6200 Series, 6200MX, 6200NT, 6220, 6230, 6260	✗	✗	S
VersaPro NX	LaVie NX LW23C/52, LaVie NX LW23D, LaVie NX LW26H, LaVie NX LW30H, LaVie NX LW33H	206	✗	P	
Optima	Centoris	25911, E+ Series, EF6C, EW1, EW2G, L2400, TW3, V470, V662, V670, V862, V870, W Series, ZW1, ZW9	206	✗	P
	Centoris	F Series, G Series	206	✗	✗
	ProLite	K Series	207	✗	T
Packard Bell	EasyNote	G5	207	✗	T
	EasyNote	1800DR, C16, C3, R8	206	✗	P



Power your laptop anywhere



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU 90W AC/DC - AP64AU	75W AC	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Panasonic	ToughBook	CF01, CF11, CF17, CF170, CF25, CF27, CF270, CF28, CF33, CF34, CF35, CF37, CF370, CF380, CF45, CF47, CF48, CF61, CF62, CF63, CF71, CF72, CFM34, CFR, CFT, CFV25, CFV41	✗	N	✗
	ToughBook	CF19, CF29, CF50, CF73, CFR1, CFT1, CFT2, CFW2, CF51	104	✗	✗
Samsung	NoteMaster	486C/25	205	M	✗
	Sens	700, 800	✗	N	✗
	Sens	500, 810	209	✗	N
	SensPro	500, 505, 520, 521, 525	209	✗	N
Sony	PictureBook	C1X	✗	N	✗
	Vaio	B55T, C1MHP, C1MT, C1MT1, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, PCG-C1MAH, PCG-C1MEL, PCG-C1MTL, PCG-SR19GKRT, PCG-SR19GT, PCG-SRX55H, PCG-SRX55L, PCG-SRX55TH, PCG-SRX55TL, PCG-SRX87, PCG-TR1, PCG-TR1L, PCG-TR1MP, PCG-TR1S, PCG-TR2, PCG-TR2L, PCG-TR2MP, PCG-TR2S, PCG-TR3, PCG-TR3AP3, PCG-TR3S, PCG-TR5AP, PCG-TR5L, PCG-TR5MP, PCG-V505AK, PCG-V505ECP14, PCG-V505GL, PCG-V505GP, PCG-V505GSP, PCG-V505L, PCG-V505MLP, PCG-V505MNP, PCG-V505MNSP, PCG-V505MP, PCG-V505MSP, PCG-V505MZL, PCG-V505P, PCG-V505SP, PCG-Z1GP, PCG-Z1LP, PCG-Z1MP, PCG-Z1RGP, PCG-Z1RLP, PCG-Z1VGP, PCG-Z1VJP, PCG-Z1VLP, PCG-Z1VXZLP, PCG-Z1XGP, PCG-Z1XJP, PCG-Z1XLP, PCG-Z1XMP, PCG-Z1XSP, S150, S150P, S18GP, S26TP, S28TP, S36GP, S36TP, SR1, SR11K, SR17, SR17K, SR17G, SR19G, SR1K, SR21, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T17TP, T26SP, T37GP, T37SP, TR1, TR1A, TR1AP, TR2, TR2A, TR2AP1, TR2AP3, TR3, TR3A, TR3AP1, TR3AP2, TR5GP, V505A, V505AC, V505AX, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P2, V505DC1P7, V505DC1PC, V505DC1PF, V505DC21, V505DC2P1, V505DX, V505DXP, V505EC, V505EC29, V505ECP1, V505ECP29, V505ECP8, V505EX, V505EXP, V505GP, V505MP, V505P, VGN-B100B, VGN-B100B01, VGN-B100B02, VGN-B100B03, VGN-B100B04, VGN-B100B07, VGN-B100B08, VGN-B100B09, VGN-B100B28, VGN-B100GP, VGN-B1VP, VGN-B1XP, VGN-B3VP, VGN-B3XP, VGN-B55C, VGN-B55G, VGN-B55L, VGN-B55S, VGN-B66GP, VGN-B66SP, VGN-B77GP, VGN-B77SP, VGN-B88C, VGN-B88GP, VGN-B88L, VGN-B99C, VGN-B99GP, VGN-G11VN/T, VGN-G11XN/B, VGN-S16GP, VGN-S16LP, VGN-S16SP, VGN-S170, VGN-S170P6, VGN-S18GP, VGN-S18LP, VGN-S18SP, VGN-S1HP, VGN-S1VP, VGN-S1XP, VGN-S25C, VGN-S260, VGN-S260P, VGN-S26C, VGN-S26GP, VGN-S26LP, VGN-S26SP, VGN-S270, VGN-S270B, VGN-S270B13, VGN-S270P, VGN-S27C, VGN-S28C/P, VGN-S28GP, VGN-S28LP, VGN-S28SP, VGN-S2HP, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S360, VGN-S360P, VGN-S36C/B, VGN-S36C/S, VGN-S36GP/S, VGN-S36LP/S, VGN-S36SP, VGN-S38CP/B, VGN-T140P/L, VGN-T140P/LKIT1, VGN-T140P/LKIT2, VGN-T150/L, VGN-T150/LKIT2, VGN-T150P/L, VGN-T150P/LKIT1, VGN-T150P/LKIT2, VGN-T150P/T, VGN-T15C/S, VGN-T15C/T, VGN-T160P/L, VGN-T160P/LKIT1, VGN-T160P/LKIT2, VGN-T16GP/S, VGN-T16LP, VGN-T16RLPS, VGN-T16SP, VGN-T170P/L, VGN-T17C/S, VGN-T17GP, VGN-T17GP/S, VGN-T17GP/T, VGN-T17LP, VGN-T1XP/L, VGN-T1XP/T, VGN-T240P/L, VGN-T250/L, VGN-T250P/L, VGN-T250P/S, VGN-T260P/L, VGN-T26C/L, VGN-T26C/T, VGN-T270P/L, VGN-T27C/L, VGN-T27GP, VGN-T27GP/L, VGN-T27GP/S, VGN-T27LP/L, VGN-T27LP/S, VGN-T27TP, VGN-T2XP/L, VGN-T2XP/S, VGN-T340P/L, VGN-T350/L, VGN-T350P/L, VGN-T350P/S, VGN-T350P/T, VGN-T360P/L, VGN-T370P/L, VGN-T37C/L, VGN-TX15C, VGN-TX16C, VGN-TX16GP/W, VGN-TX16SP/W, VGN-TX17C, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP/W, VGN-TX1XP/B, VGN-TX1XP/L, VGN-TX27GP/B, VGN-TX27GP/T, VGN-TX27G-PB, VGN-TX27GPT, VGN-TX27GPW, VGN-TX27TP, VGN-TX2HP/W, VGN-TX2XP/B, VGN-TX36GP/W, VGN-TX37, VGN-TX37GP/B, VGN-TX37GP/T, VGN-TX37GP/W, VGN-TX3HP/W, VGN-TX3XP/B, VGN-TX3XP/L, VGN-TX57GN, VGN-TX5MN/W, VGN-TX5VN/L, VGN-TX5XN/B, VGN-TX610P/B, VGN-TX630P/B, VGN-TX650P/B, VGN-TX651P/B, VGN-TX670P/B, VGN-TX670P/W, VGN-TX690P/LKIT1, VGN-TX750P/B, VGN-TX770P/B, VGN-TX770P/T, VGN-TX770P/W, VGN-TX790P/L, VGN-TX850P/B, VGN-TXN15P/B, VGN-TXN15P/W, VGN-TXN17P/B, VGN-TXN17P/T, VGN-TXN19P/L, VGN-TXN25N/B, VGN-TXN25N/W, VGN-TXN27N/B, VGN-TXN27N/T, VGN-TXN27N/W, VGN-TXN29N/L, VGN-TZ27GNB, VGN-TZ36GN, VGN-U750P, VGN-U8G, VGN-UX17GP, VGN-UX180P, VGN-UX180PKIT1, VGN-UX1XN, VGN-UX27GN, VGN-UX280P, VGN-UX380N, VGN-UX390N, VGN-X505VP, VGN-Y18C, VGN-Y18GP, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP1KITB, Z1RAP2, Z1RAP3, Z1SP, Z1VA, Z1VAP1, Z1VAP1KITB, Z1VAP2, Z1VAP2KITB, Z1WA, Z1WAMP1, Z1WAMP2, Z1WAMP3, Z1WAP, Z1XGP, Z1ZAP1, Z505AX, Z505AXP	✗	N	✗



AC wall



DC auto



DC air



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - JPM64U	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Sony	Vaio	VGN-FS315B, VGN-FS315E, VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S, VGN-FS315Z, VGN-FS35C, VGN-FS35GP, VGN-FS35SP, VGN-FS38C, VGN-FS38GP, VGN-FS38SP, VGN-FS395VP, VGN-FS415B, VGN-FS415E, VGN-FS415M, VGN-FS415S, VGN-FS485B, VGN-FS48GP, VGN-FS495VP, VGN-FS500B, VGN-FS515B, VGN-FS515E, VGN-FS515H, VGN-FS550F, VGN-FS610FP, VGN-FS615FP, VGN-FS640FP, VGN-FS650F, VGN-FS655FP, VGN-FS670FG, VGN-FS710FP, VGN-FS715F, VGN-FS730F, VGN-FS740FP, VGN-FS745P/H, VGN-FS750F, VGN-FS755FP, VGN-FS760/W, VGN-FS770FG, VGN-FS775P/H, VGN-FS790, VGN-FS810/W, VGN-FS810FP, VGN-FS812F, VGN-FS815F, VGN-FS8900, VGN-FS930F, VGN-FS970P, VGN-FZ25G, VGN-FZ27G, VGN-FZ28G, VGN-FZ38GU, VGN-FZ55GN, VGN-N110G/W, VGN-N11H/W, VGN-N11M/W, VGN-N11S/W, VGN-N130G/W, VGN-N130P/B, VGN-N150G/W, VGN-N150P/B, VGN-N160G/W, VGN-N170G/T, VGN-N170G/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21S/W, VGN-N220E/B, VGN-N220E/W, VGN-N230E/B, VGN-N230E/T, VGN-N230E/W, VGN-N230N/B, VGN-N250E/W, VGN-N250N/B, VGN-N270E/T, VGN-N270E/W, VGN-N29VN/B, VGN-N320E/B, VGN-N320E/W, VGN-N350E/B, VGN-N350E/T, VGN-N350E/W, VGN-S380, VGN-S380B, VGN-S38GP, VGN-S38GP/B, VGN-S38LP/B, VGN-S38SP, VGN-S3HP, VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S45, VGN-S45SP, VGN-S46, VGN-S460, VGN-S460/B, VGN-S460P/B, VGN-S46GP/S, VGN-S470P/S, VGN-S470P/SKIT, VGN-S470P/SKIT7, VGN-S47SP, VGN-S48, VGN-S480, VGN-S480B, VGN-S48GP/B, VGN-S49, VGN-S4HP, VGN-S4HP/B, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP, VGN-S4XRP/B, VGN-S55, VGN-S550P/S, VGN-S55SP/S, VGN-S56, VGN-S560P/B, VGN-S56GP/S, VGN-S570P/S, VGN-S57SP/B, VGN-S58, VGN-S580, VGN-S58GP/B, VGN-S59, VGN-S5HP, VGN-S5M/S, VGN-S5VP, VGN-S5XP/B, VGN-S660/B, VGN-S67GP/S, VGN-S67TP, VGN-SZ110/B, VGN-SZ120P, VGN-SZ120P/B, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ17G, VGN-SZ210P/B, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ23TP/B, VGN-SZ240, VGN-SZ250P/C, VGN-SZ260P, VGN-SZ26TP/C, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ28TP/C, VGN-SZ2VP/X, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ38GP, VGN-SZ390, VGN-SZ390PW1, VGN-SZ3HP/B, VGN-SZ3VP/X, VGN-SZ3VWP/X, VGN-SZ3XP/C, VGN-SZ3XWP/C, VGN-SZ430N/B, VGN-SZ440, VGN-SZ44GN, VGN-SZ450N/C, VGN-SZ460N/C, VGN-SZ470N/C, VGN-SZ480, VGN-SZ48GN, VGN-SZ491N/X, VGN-SZ4MN/B, VGN-SZ4VN/X, VGN-SZ4VWN/X, VGN-SZ4XWN/C, VGN-SZ55GNB	209	✘	N
Toshiba	Libretto	U100 (PLU10A-00500W), U100 (PLU10A-00900W)	205	M	✘
	Portégé	3480CT (PP348E-6PU83), M500 (PPM51A-01600D), M500 (PPM51A-01P00L), R200 (PPR21A-00W01E), R400 (PPR40A-00H00L), R400 (PPR40A-01000L), R500 (PPR50A-00V01X), R500 (PPR50A-00V05C), R500 (PPR50A-02T01X), R500 (PPR50A-04N05C), R500 (PPR50A-04P05C), R500 (PPR50A-07Q05C), R500 (PPR50A-07R05C), R500 (PPR50A-07S05C), R500 (PPR50A-SP101X), R500 (PPR50A-SP105C), R500 (PPR50A-SSD3G), M400 (PPM40A-00F00G), M400 (PPM40A-08M00G), M400 (PPM40A-1HD03D), M400 (PPM40A-1HE03D), M400 (PPM40A-3JS03Y), M400 (PPM40A-3JW03D), M405 (PPM40A-3NY03Y), M700 (PPM70A-00W01G), M700 (PPM70A-01Q01G), M700 (PPM70A-03P01G), M700 (PPM70A-0G301G), M700 (PPM70A-0Q201G)	205	M	✘
	Portégé	M600 (PPM60A-035011), M600 (PPM60A-05F01D), M600 (PPM60A-05R011), M600 (PPM60A-06T01D), M800 (PPM80A-01900P), M800 (PPM80A-03H009), M800 (PPM81A-01U01J), M800 (PPM81A-02201J)	206	✘	P
	Satellite	A200 (PSAF6A-02C01N), A200 (PSAFCA-01400J), A200 (PSAFCA-01600K), A200 (PSAFCA-01C00J), A200 (PSAFCA-01H00J), A200 (PSAFCA-01K00J), L300 (PSLB0A-02L022), L300 (PSLB0A-02M027), L300 (PSLB0A-08C022), L300 (PSLB0A-08D022), L300 (PSLB0A-08E022), L300 (PSLB0A-08H022), L300D (PSLC8A-02000Y), L300D (PSLC8A-02200Y), M200 (PSMC0A-01X00N), M200 (PSMC0A-02G00M), M200 (PSMC3A-04P008), M200 (PSMC3A-06N008), M200 (PSMC6A-03Q00S), M300 (PSMD0A-02700E), M300 (PSMD0A-04S00E), M300 (PSMD4A-023008), M300 (PSMDCA-01800C), M300 (PSMDCA-01900C), M300 (PSMDCA-01T00C), P200 (PSPBGA-01W015), P200 (PSPBGA-01X015), U300 (PSU30A-02Y01U), U300 (PSU30A-05302P), U300 (PSU30A-0DJ02P), U400 (PSU40A-01M001), U400 (PSU40A-01S001), U400 (PSU44A-00H00C), U400 (PSU44A-00J00C), 1710/1730 (PS170A-0002C), 1730/1750 (PS173A-21KK3), 3000 (PS302A-018XK), A200 (PSAF0A-02L01C), A200 (PSAF0A-03M019), A200 (PSAF0A-04X019), A200 (PSAF0A-04Y019), A200 (PSAF0A-0CQ01C), A200 (PSAF0A-0EV019)	206	✘	P
	Satellite	M100 (PSMAAA-01M006), M100 (PSMAAA-020006), M100 (PSMAAA-026007), M110 (PSMB0A-01J00D), M110 (PSMB0A-01L00D), P100 (PSPA EA-00G00G), 1800 (PS181X-00XXX), 1800 (PS181X-AAAAX), A100 (PSAA8A-19Y03Q), A100 (PSAA8A-1HQ03R), A100 (PSAA9A-118038), A100 (PSAANA-04E005), A100 (PSAARA-054007), A100 (PSAARA-055007), A100 (PSAARA-057007)	205	M	✘
	Satellite Pro	L30 (PSL30A-00100E), L300 (PSLB1A-01L019), L300 (PSLB1A-01N008), L300 (PSLB1A-02C01E), L300 (PSLB1A-02D008), L300 (PSLB1A-02R01E), L300 (PSLB1A-02S008), M200 (PSMC4A-00C001), M200 (PSMC4A-01N00C), M300 (PSMD1A-005004)	206	✘	P
	Satellite Pro	A120 (PSAC0A-00D002), A120 (PSAC1A-045005), A120 (PSAC1A-073004), A120 (PSAC1A-0QP01X), A120 (PSAC1A-0QV03J), A120 (PSAC1A-0R903H), A120 (PSAC1A-0VW03H), A120 (PSAC1A-0VX03J), P100 (PSPA4A-016002)	205	M	✘
	Satellite Pro	S200 (PSSA1A-00V008), S200 (PSSA1A-0G9007)	205	M	✘



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - AP164U	75W AC	90W AC

Manufacturer	Model Name	Series	Tip	Tip	Tip
Toshiba	Tecra	A6 (PTA63A-002002), A7 (PTA71A-012003), A7 (PTA71A-0DU003), A7 (PTA71A-0DW003), A7 (PTA71A-1EU003), A8 (PTA83A-0HV041)	205	✗	✗
	Tecra	A8 (PTA83A-042012), A8 (PTA83A-054012), A8 (PTA83A-056012), A8 (PTA83A-0HU041), A8 (PTA83A-0HW041), A8 (PTA83A-0K5041), A10 (PTSB0A-002001), A10 (PTSB0A-006001), A10 (PTSB0A-00E001), A6 (PTA61A-093005), A9 (PTS52A-0CT017), A9 (PTS52A-0CU03F), A9 (PTS52A-0CV03F), A9 (PTS52A-0CW03F), A9 (PTS52A-0GF03F), M10 (PTMB0A-00M001), M5 (PTM51A-0EG007), M5 (PTM51A-0EJ007), M5 (PTM51A-0RL05P), M5 (PTM51A-0RM05P), M5 (PTM51A-0RW05P), M7 (PTM71A-01101H), M9 (PTM90A-08P03H), M9 (PTM90A-0CL03H), M9 (PTM91A-05504L), M9 (PTM91A-0E104L), M9 (PTM91A-0EY04L), M9 (PTM91A-0U204L), P (PTS40A-02100V), P (PTS40A-02800V), P5 (PTS53A-0FR03X), P5 (PTS53A-0FS03X), S3 (PTS30A-094008), S3 (PTS30A-0CG008), A8 (PTA83A-04G012), A8 (PTA83A-0HV041), A9 (PTS52A-00T00F), A9 (PTS52A-00U00F), A9 (PTS52A-00V00F), A9 (PTS52A-023017), A9 (PTS52A-0EV017), A9 (PTS52A-0EW03F), A9 (PTS52A-0EX03F), A9 (PTS52A-0EY03F), M5 (PTM51A-1FQ07P), M9 (PTM90A-01V00K), M9 (PTM90A-0C603H), M9 (PTM91A-035002), M9 (PTM91A-036002), M9 (PTM91A-037002), M9 (PTM91A-0MF04L), M9 (PTM91A-0MG04L), M9 (PTM91A-0T304L), P5 (PTS53A-007006), P5 (PTS53A-009006), P5 (PTS53A-01G006), P5 (PTS53A-02F01D), P5 (PTS53A-05H03X), P5 (PTS53A-05Y01D), P5 (PTS53A-05Y03X), P5 (PTS53A-06003X), P5 (PTS53A-0FT03X)	205	M	✗
WinBook	WinBook	J1, N, Si, Si2, X1, X2, X4, XL, XLi, XP, Z	205	✗	✗