


Addendum

How to use the voice recorder

This presenter is equipped with a voice recording function. The recorded data is stored into the SD memory card. (SD card not included)

1. Switch the presenter's power to "Off / Card reader" position before inserting your SD card. (Maximum 1G SD memory card)
2. Insert the SD memory card into the presenter's card slot completely and in the proper direction. Please make sure the SD card is formatted and the protection lock is in "write" position.
3. Switch the presenter to "Presenter / On" position. The recording function is now ready. Press once and release the "voice record button" to start recording. The LED beneath the button will glow red when recording is in progress.



4. Press once and release the "voice record button" to end recording.



Note: Please note that it will take some time for the card reader to finish processing voice recording after turning off the recording function. The more data is stored in the memory card the longer it will take for the red light to turn off. This is not a defect; this is the way card reader operates. Please make sure the record indicator LED is off.

5. Always speak into the microphone positioned above the laser button.

When the SD card is full, the LED under the recording button will flash twice per second and the recording will stop functioning. If the presenter is low in battery, the LED under the Targus logo will flash continuously until the power is completely out. This is an indication that there's only enough power for approximately 30 minutes (depending on the usage) -- you should replace the batteries now.



Note: To preserve battery life, please ensure the power switch is in "off" position when the presenter is not use.