

AVERATEC	
3A	3120V, 3150HS, 3150P, 5100, 5110H
Compaq	
2A	Armada: 110, E500, E500S, M300, M700, V300
	Evo: N110, N150, N200, N400c, N410c, N600c, N610c, N620C, N800c, N800v
	Presario: 300, 2800 series, 2900 series, X1000, X1001
	Prosignia: 170, 190
3A	Evo: N115, N160, N180
	Presario: 700 series, 800 series, 1000 series, 1200 series, 1400 series, 1600 series, 1700 series, 1800 series, 2700 series, 12XL, 14XL, 1600i, 16XL, 17XL, 1800t, 18XL, 2700xx, X1001
	Prosignia: 150
DELL	
3A	Inspiron: 3000, 3200, 3500, 7000
9	Inspiron: 2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 5100, 7500, 8000, 8100 series
	Latitude: X200, C400, C410, C500, C510, C600, C610, C800, C810, CP, CPi, CPt, CPx, CS/CSx, LM
Fujitsu	
3A	LifeBook: A1010, C2010, C2110, C2111, C2210, E4010, E4010D, E-6624, E-6634, E-6644, E-6654, E-6664, E7010, E7110, Amilo L
11A	LifeBook: 200, 400, 500, 600, 700, 900, 270Dx, 280Dx, 420Dx, 435Dx, 531T, 535T, 555Tx, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx1, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B-2545, B-2562, B-2566, B2610, B2620, B2630, C340, C350, C352, C353, C360, C-4120, C-4235, C-5130, C-5235, C-6177, C-6320, C-6330, C-6525, C-6535, C-6537, C-6547, C-6556, C-6557, C-6577, E330, E340, E342, E350, E351, E360, E362, E370, E380, E-5140, E-5320, E-5520, E-6150, E-6520, E-6530, E-6540, E-6541, E-6550, E-6555, E-6556, E-6557, E-6570, E-6571, E-6575, E-6595, L440, L470, P-1000, P-1032, P-1035, P-1120, P-2000, P-2040, P-2046, P-2110, P-2120, P-5010, P-5010D, S-2010, S-4510, S-4542, S-5582, S6010, S6110, S6120, S6120D, Stylistic 3400, Stylistic 3500, Stylistic LT C-500, Stylistic LT P-600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120, Stylistic ST4120P, Stylistic ST4121
GATEWAY	
3A	Solo: 1100, 1150, 1200, 1400, 1450, 2150, 2500, 2550, 3100, 3150, 3300, 3350, 5150, 5300, 5350, 9100, 9150, 9300, 9500, 9550
	400SD4, 400VTX, 450ROG, 450SX4, 600YG2, 600YGR, M305, M500
HP	
2A	Tablet: TC1000, TC1100
	Desktop Notebooks: NW8000, NC8000
	Business Notebooks: NC4000, NC4010, NX7000, NX7010
	Pavilion: ZT3010
3A	Omnibook: 300, 425, 430, 500, 510, 530, 900, 2000, 2100, 2103, 2105, 3000, 3100, 3101, 4000, 4100, 4101, 4103, 4105, 4150, 5000, 5500, 5700, 6000, 6100, 7100, 7103, 7150, 600c, 600ct, 900b, vt6200, xe series, xt series
	Pavilion: 2105, 3101, 4101, 4103, 4105, 5159, N3100 series, N3200 series, N3300 series, N3400 series, N5100 series, N5200 series, N5300 series, N5400 series, N6190, N6195, N6300 series, N6400 series, xf series, xh series, xt series, xu155, xz series, ze series, zt series, zu1155, zu1175
IBM	
4A	ThinkPad: 600E, 600X, 770E, 770ED, 770X, 770Z, A series, R series, T series, X series, Transnote
Panasonic	
4A	Toughbook: CF-R1, CF-T1, CFT2
11A	Toughbook: CF01, CF11, CF17, CF170, CF270, CF370, CF380, CF25, CF27, CF28, CF33, CF34, CF35, CF37, CF41, CF45, CF47, CF48, CF50, CF61, CF62, CF63, CF71, CF72, CF73, CF-M34, CF-V25, CF-V41
Sony	
11A	Picturebook: C1X
	VAIO: C1MHP, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, SR11K, SR17, SR17K, SR1K, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, TR1A, TR1AP, TR2A, TR2AP1, TR2AP3, V505A, V505AC, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP, VX71P, Z1, Z1A, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3,
12A	VAIO: 81, 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 812, 818, 838, C1XW, F Series, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FX series, GRS series, GRX series, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PG32, QR10, QR20, R500, R505CT, R505D, R505DT, R505J, R505T, R505TE, R505TEK, R505TS, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, V505AP, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK
Toshiba	
3A	Satellite: 1000, 1005, 1100, 1200, 1605, 1625, 1675, 1695, 1715, 1730, 1735, 1750, 1755, 3000, 3005
6A	Portégé: 2000, 2010, 4000, 4005, 4010, 3500 Tablet, 3505 Tablet, R100, M100, M200, M205
	Satellite: 1400, 1405, 1410, 1415, 1555, 1800, 1805, 2060, 2065, 2100 series, 2200 series, 2400, 2405, 2410, 2415, 2500 series, 2600 series, 2700 series, 2800, 2805, 4000 series, 4100, 5005, 5105, 5200, 5205, A10, A15, M20, M30, M35
	Satellite Pro: 4200, 4600, 6000, 6100, M10, M15
	Tecra: 8000, 8100, 8200, 9000, 9100, A1, M1, M2, S1
Winbook	
3A	J1, N, Si, Si2, X1, X2, X4, XL, XLI, XP, Z